



TruGolf®

# STARTER 10

Assembly Guide



# THANK YOU

---

The Road to Better Golf Starts Here!

In this guide, you will find everything you need to complete the assembly of your new STARTER 10 Simulator. You will also find a few helpful installation tips and tricks that will ensure that you have the best possible experience.

Welcome to the TruGolf Team!  
We can't wait to show you what's possible.

# TABLE OF CONTENTS

---

|                |     |
|----------------|-----|
| SPECS & SAFETY | 1-2 |
|----------------|-----|

---

|                 |   |
|-----------------|---|
| WHAT'S INCLUDED | 3 |
|-----------------|---|

---

|                            |      |
|----------------------------|------|
| FRAME & ENCLOSURE ASSEMBLY | 4-16 |
|----------------------------|------|

---

|                   |    |
|-------------------|----|
| OVERHEAD MOUNTING | 17 |
|-------------------|----|

---

# SPECIFICATIONS

---

Product Name ..... Starter 10 Enclosure

Enclosure ..... (H) 8'4" x (W) 10'10" x (D) 13'7"  
Dimensions

Recommendations ..... A step-stool or ladder, as well  
as help from an additional  
person, will be needed  
during assembly.

Weight ..... 117 LBS.

Color ..... Black Skins & Frame.  
White Impact Screen.

Screen Dimensions ..... 10'1" W x 7'7" H  
(12'7" Diagonal)

Recommended ..... Minimum of 12' width,  
Room Size ..... 18' length, and 9' ceiling  
height.



# SAFETY INSTRUCTIONS

---

- Please pay close attention and make sure children, pets, and other spectators are at a safe distance when swinging a golf club inside the enclosure.
- Take every precaution to protect ceilings, walls, windows, vehicles, and neighboring homes.
- Be aware of where you stand and walk, especially when others are swinging golf clubs or hitting balls into the screen.
- Make sure the setup is far from gas lines, electric heaters, fireplaces, candles, or any other source of heat or fire hazard.
- When not in use, store neatly in a cool, dry location, that's protected from weather elements and direct sunlight.
- TruGolf is not responsible for any damage to property and/or any personal injury.
- During assembly, check that all enclosure components are well fit and fastened to prevent loosening during use.
- Do not hang from the enclosure.

# WHAT'S INCLUDED

---

## STARTER 10 ENCLOSURE



(18) COLOR CODED SNAP-BUTTON POLES

(1) STARTER 10 PREMIUM IMPACT SCREEN

(1) BLACK NYLON SURROUND

(4) FOAM PADDING STRIPS

(2) L-SHAPED CONNECTORS

(6) 3-WAY CONNECTORS

(80) BALL BUNGEEES

# FRAME ASSEMBLY

---

Lay out poles and connectors.  
Organize by color.



(4) PURPLE poles with a single stripe on one end and double stripes on the opposite end.



(4) BLUE poles with single stripes on both ends.



(3) YELLOW poles with single stripes on one end and double stripes on the opposite end.




# FRAME ASSEMBLY

---



(4) GREEN poles with single stripes on both ends.




(3) ORANGE poles with single stripes on both ends.

TIP: In the following steps, you will connect the GREEN single stripe end to the connector pieces. You will connect the ORANGE single stripe ends to the YELLOW double stripe ends.



# FRAME ASSEMBLY

Assemble the back lower poles first. Attach a YELLOW pole to an ORANGE pole. After, attach a 3-way connector to each end.



**REMEMBER:** Connect the double striped end of the YELLOW pole to the single striped end of the ORANGE pole. The 3-way connectors will attach to the single striped end of each pole.

Assemble the entire lower section by attaching (2) GREEN poles to the 3-way connectors, and then attach the (2) L-shaped connectors to the ends of the (2) GREEN poles.



# FRAME ASSEMBLY

---

Connect (4) BLUE poles to the corner connectors that will act as bottom uprights for the structure.



**TIP:** At this point in the assembly, make sure button snaps are fully engaged in each fitting. Also, this would be a good time to place the structure near its final location due to the added weight of the screen and skin in future steps.

# FRAME ASSEMBLY

---

Connect (4) PURPLE poles to the BLUE uprights to complete the vertical assembly. Next, attach the (4) remaining 3-way connectors to the open ends of the PURPLE poles.




# FRAME ASSEMBLY

---

Starting with the back section, attach (1) ORANGE pole to the back-right 3-way connector.

Then attach (1) YELLOW pole to the ORANGE pole and that YELLOW pole to the back-left 3-way connector.

Repeat these same steps for the front facing upper section.






# FRAME ASSEMBLY

---

To complete the frame structure, attach the (2) remaining GREEN poles to the open 3-way connectors at the top.



# ENCLOSURE ASSEMBLY

---

In this section, you will attach the black skin and the white impact screen to the frame. You will need a ladder and an additional person to assist with the following steps.

Unfold the black skin and position it around the outside of the frame.



1) Make sure that the velcro strips of the skin will be facing the inside of the frame assembly.

2) Make sure the grommet holes of the skin are positioned along the back of the frame.



# ENCLOSURE ASSEMBLY

---


Unfurl the black skin, bring it over the top of the GREEN pole, and hang the skin across the structure so it drapes over the opposite GREEN pole and down the opposite side of the frame.



Once the black skin is in place, remove the velcro cover strips and begin wrapping the skin's panels around the poles.

# ENCLOSURE ASSEMBLY

**TIP:** Connect the bottom flaps of the black skin first. Start by sliding the lowest inside flaps of the skin under the bottom poles and then folding them back up and fastening them in place to the velcro strip.




Once the entire black skin has been fastened in place using the velcro strips, finish connecting the skin to the frame with the bungee balls.



Remember to position the balls towards the inside of the enclosure.


Finish connecting the black skin to the frame using the bungee balls before moving on to hang the white impact screen.



# ENCLOSURE ASSEMBLY

**TIP:** Before handling the impact screen, wash your hands thoroughly to avoid blemishes or stains on the white material.

Make sure the floor is clean too!



Begin by using (4) bungee balls to attach the screen to the four corners.

Thread the bungee cords through the grommet holes in the screen, then wrap them around the pole.

Make sure that the bungee ball is positioned towards the outside of the enclosure.

Thread and wrap a bungee ball through every grommeted hole of the impact screen.

\*Some (not all) grommet holes in the impact screen will match up with grommet holes in the black skin.



# ENCLOSURE ASSEMBLY

---

The (4) foam pads can now be added to the enclosure.

There are (2) long pads that attach to the velcro along the top and bottom of the screen, and (2) shorter pads that attach to the two vertical sides of the screen.





# ENCLOSURE ASSEMBLY

---




Your new Starter 10 Enclosure is now complete!

Congratulations!

# OVERHEAD MOUNTING

## NEC ME453X Projector

Projector lens should be mounted 14.5'-15.5' from the screen.



*\*For APOGEE mounting instructions please refer to the APOGEE manual.*

# STARTER 10 ENCLOSURE

**PLAY, IMPROVE, ENJOY!**

We stand by all of our products, so if you're not 100% satisfied, please contact our U.S. Based Support Team so that we can make it right.

[TRUGOLF.COM/SUPPORT](https://TRUGOLF.COM/SUPPORT)

Direct: (801) 677-1123  
Toll-Free: (877) 711-6691  
Monday-Friday, 9-5 MST













**TruGolf.com**

**(877) 711-6691**